



Fix the Short in the Plug Guide

If the power cord is plugged in correctly and the prongs are not damaged, there may be a short in the wire. This guide will help you fix this problem.

Written By: Rosana Cheruvelil





TOOLS:

- [Electrical Tape in 6 Assorted Colors](#) (1)
-

Step 1 — Fix the Short in the Plug Guide



- Find the power cord.

⚠ Make sure that it is unplugged from the outlet. This is to make sure that no power is flowing through and you are not injured.

Step 2



- Locate all exposed portions of the wire.
- Tape over any exposed portions of the wire with electrical tape.

⚠ Use this power cord temporarily.

Step 3



- Plug the power cord into the outlet and make sure the power cord is connected to the device. If not, connect the power cord to the back of the device.
- Replace the damaged cable by purchasing a new cable at your local hardware store.

This document was last generated on 2017-06-22 04:44:14 PM.